

How to set up voice card

for Rangemaster X3 system

User Manual

Revision date: 22.06.2023 Firmware version: A34 from 22th of June 2022

PROFESSIONAL SHOOTING GROUND AUTOMATION



1. VOICE CARD PCB INSTALLATION

It is very crucial to insert the voice card PCB correctly otherwise it may create shortcut and burn down the PCB and the motherboard. When inserting the voice card, make sure that the hole of the PCB matches the hole of the mother board (see picture below):





2. SETTING UP

To set up the voice card use 4 push buttons bellow the display.



Push button	Description
PROG/BACK	Enter the Setting menu (keep pressed); Go back to the previous section without saving changes (if were made)
UP/DOWN	Scroll back and forth;
SAVE/NEXT	Confirm the choice and save the changes

To enter the setting menu keep pressed **PROG/BACK** button.



	Menu section	Used for
1.	Choose Language	Here you can set up the interface language: • English • German (Deutsch) • Russian (Русский) To change the language use UP/DOWN buttons. To save and go to the next section use SAVE/NEXT button. To go back without saving changes use PROG/BACK button.
2.0	Config for	We choose for which discipline we make the settings: - SKEET - TRAP - COMPAK To change the discipline use UP/DOWN buttons. To save and go to the next section use SAVE/NEXT button. To go back without saving changes use PROG/BACK button.
2.1.	Voice Level	 Adjusts the voice reception level (sensitivity). Min. value: 10, max. value: 80. Lower value – more sensitive, higher value means you have to call louder. To change the value use UP/DOWN buttons. To save and go to the next section use SAVE/NEXT button. To go back without saving changes use PROG/BACK button.
2.2	Supress Level	Adjusts suppression level of non active microphones. In very high ambient noise ranges a higher suppression level might be necessary. If the noise level exceeds the number, then the system considers it to be noise. Should be adjusted during windy weather Min. value: 0 max. value: 20. 0 = suppression is disabled 1 = max. noise suppression 20 = min. noise suppression To change the value use UP/DOWN buttons. To save and go to the next section use SAVE/NEXT button. To go back without saving changes use PROG/BACK button.
2.3	An. frame size	Here you set the frame size I for the voice analysis Min. value: 1, max. value: 10. To change the value use UP/DOWN buttons. To save and go to the next section use SAVE/NEXT button. To go back without saving changes use PROG/BACK button.



2.4	Frame-Dim.	Here you set the frame size II for the voice analysis Min. value: 10, max. value: 50. To change the value use UP/DOWN buttons. To save and go to the next section use SAVE/NEXT button. To go back without saving changes use PROG/BACK button.
2.5.	Shot Level	Adjusts the trigger for recognizing a shot. Lower level means that muzzle can be further away from the microphone and still can detect shot positive. E.g. lover values are necessary for subsonic loads. Take care: lower value can give false positive on very loud and long pull calls. Min. value: 10, max. value: 50. Shot is recognized – depends on quality of microphones and the quality of cables! To change the value use UP/DOWN buttons. To save and go to the next section use SAVE/NEXT button. To go back without saving changes use PROG/BACK button.
FFT-Se	<u>tup: please do NOT Change</u>	Values:
2.6	FFT HF Level.:	Recommended value: 20 (Do not change!)
2.7	FFT HF Frame.:	Recommended value: 6 (Do not change!)
2.8	FFT LF Level.:	Recommended value: 1 (Do not change!)
2.9	FFT LF Frame:	Recommended value: 5 (Do not change!)
2.10	FFT Border:	Recommended value: 10 (Do not change!)

* To enter the quick setup menu keep the UP button pressed.



2.1. RECOMMENDED VALUE OF SETTINGS

Standard setting (normal ambient noise), little wind.

SETTING	SKEET	TRAP	СОМРАК
Voice Level	36-42	26-30	36-42
Suppress Level	15	15	15
An. frame size	4	3	4
Frame-Dim	40	30	40
Shot level	15	15	15

Settings for stormy/gusty wind:

Please use the Rangemaster microphone coverings!

SETTING	SKEET	TRAP	СОМРАК
Voice Level	42-46	31-34	36-42
Suppress Level	10	10	10
An. frame size	4	4	4
Frame-Dim	30	30	30
Shot level	15	15	15

3. QUICK SETUP MENU (CHANGING THE STANDARD VOICE RECOGNITION TO FFT (BETA))

To enter the quick setup menu keep the UP button pressed. It allows to setup the voice card while having microphones not in a random way, but for a specific level of voice, noise, and so on. When setting in quick setup mode the user has the opportunity to observe the detected level of a voice or shot - this is shown by a filled rectangle.





RANGEMASTER SYSTEMS-Maxima WarenhandelsGmbH 8010 Graz, Dr. Robert Graf Straße 64/9, Austria/Europe

Web: www.rangemaster.at Mail: info@rangemaster.at Tel:+43 699 10403204 Fax:+43 720 920 195 Date:22/06/23 Page: 4 Firmware version A34 22/06/22



Important: when configuring "on the fly", the system is not triggered.

The user has the ability to observe the LEDs under the display. The lower left LED indicates voice detection, the lower right LED indicates a shot. That is, if the board detects a voice call during configuration, the lower left LED will flash, but the signal will not go to the main board and the user will be able to continue to settings. The same applies to the setting of shots, only the lower right LED will flash.

FFT will only work if you press the UP button while waiting for a voice command. Then the screen will display the inscription FFT, the name of the discipline and the channel number. In this case, it will be possible to observe the spectrum of the signal on the selected channel.

To turn off the FFT mode, press the DOWN button.

The board remembers whether the FFT mode was turned on or off, so after turning the power off and on, the mode that was before shutdown (with or without FFT) will be set.



4. LEDS

There are 8 leds on the pcb with indicate microphones: 1-8 for skeet and 1-5 for trap and compak. In waiting mode all LEDs should be off and blink only when target is called or shot is made.

If inactive microphone LED is on or blinking - there is a problem with the microphone.





5. MESSAGES ON THE DISPLAY

Message on the display	Description
	Waiting mode (moving Rangemaster logo on the display) - no active microphones
Waiting for Call	The system is active. Microphone waiting for voice call
Waiting for Shot	After the voice call while releasing of the target, the system is waiting for a shot to shift to the next microphone
ERROR! Wrong Command	Call Rangemaster manager

6. RECOMMENDED POSITION OF MICROPHONES

To provide the correct work of the system we ask to use the following recommendations for placing the microphones.

TRAP + COMPAK

All microphones should be placed in front of shooting stations. Distance between front edge of the shooting station and the middle of the microphone pedestal should be 0.5-0.75m.



SKEET

Distance between front edge of the shooting station and the middle of the microphone pedestal should be 0.5-0.75m.



Microphones on station 1,4,7,8 should be placed in front of the shooting station. Microphone 2,3 should be placed on the left side from the shooting stations (around 50 cm to the left). Microphone 5,6 should be placed on the right side from the shooting stations (around 50 cm to the left).



7. SOFTWARE UPDATE (FLASHING OF THE FIRMWARE)

To update the software you need the following hardware and software:

- programmer ST-LINK V2 (you can use clone)

- ST-LINK Utility \rightarrow to download use the link <u>https://www.st.com/en/development-tools/stsw-link004.html</u>

- Latest version of the SW provided by Rangemaster Systems

Steps to flash the firmware:

- 1. Get newest firmware for voice card named "X3-PP-32_A034?.hex"
- 2. Setup ST-LINK Utility
- 3. Connect ST-LINK to voice card:



ST-LINK clone	Voice card
GND	G
SWCLK	С
SWDIO	D
RST	R

4. Open ST-LINK Utility

5. Click Target→Connect

遍 STM32 ST-LINK U	tility		
File Edit View Ta	arget ST-LINK E	xternal Loader Help	
🚐 🔲 🛛 💾 🕘	Connect		1
Memory display	Disconnect	√ CTRL+D	
Address: 0x080	Erase Chip	CTRL+E	32 bits
	Erase Bank1		
Device Memory Bi	Erase Bank2		
Device Memory	Erase Sectors		
	Program		



6. Choose firmware file

stm32 st-link Utility												
File	Edit	View	Target	ST-LINK		External Loa	der	Help				
	Open file CTRL+O					swv						
	Save file as CTRL+S Close File Compare two files					0x3148		Data Width	n: 3	32 bits	~	
						≂ila						
Exit				5	00 0x08003	148]				_		
	Address		0		4		8		С			ASC

7. Click Target→Program & Verify

STM32	ST-LINK	Utility				
File Edit	View	Target	ST-LINK Exter	nal Loader Help		
	Ľ,	C	onnect			
-Momory dia		Di	isconnect	CTRL+D		
Memory us	spiay	-	<u>a</u> :	CTDI F		
Address:	0x080	Er	ase Chip	CTRL+E		ľ
		Er	ase Bank1		í –	
Device Men	nory @ (Er	ase Bank2			
[X3-PP-32_A	020_2	Er	ase Sectors			
Addres	s					
0x0800000	0	Pr	rogram			
0~0800001	0	Pr	rogram & Verify	CTRL+P		-
0x0800001	0	BI	ank Check			_

8. Click Start